Omega calibre 601 · parts by number

Manual wind, centre seconds · diameter 27.90 mm · height 3.35 mm · 19,800 vph · 17 jewels · base calibre 600

Part numbers and names as printed in the Omega spare parts catalogue GF 620-3. 89 numbers.

Plates and bridges (6)

601.1000	Plate
601.1001	Barrel bridge
601.1003	Train wheel bridge
601.1005	Pallet cock
601.1007	Sweep second cock
601.1030	Balance cock

Winding and setting (20)

600.1100	Ratchet wheel
470.1101	Crown wheel
600.1102	Crown wheel core
550.1103	Crown wheel seat
330.1104	Click
240.1105	Click spring
600.1106	Winding stem
550.1107	Clutch wheel
470.1108	Winding pinion
500.1109	Setting lever
550.1110	Setting lever spring
330.1111	Yoke
360.1112	Yoke spring
601.1113	Setting wheel
600.1125	Winding stem, length 23.50 (for pocket watch)
470.1132	Pressure spring for setting lever
600.1149	Movement stem, length 10.60
550.1150	Crown stem with steel crown
550.1150a	Crown stem with crown gold plated (pink)
550.1150b	Crown stem with crown gold plated (yellow)

Check every number against your movement and supplier before ordering. Not affiliated with Omega.

Barrel, train and motion work (19)

600.1200	Barrel with arbor
600.1204	Barrel arbor
600.1208	Mainspring
550.1218	Cannon pinion, height 2.05
560.1218	Cannon pinion H2, height 2.55
550.1219	Cannon pinion H1, height 2.20
550.1224	Center wheel with cannon pinion, height 3.86
560.1224	Center wheel with cannon pinion H2, height 4.36
550.1225	Center wheel with cannon pinion H1, height 4.01
550.1231	Hour wheel, height 1.18
560.1231	Hour wheel H2, height 1.68
550.1232	Hour wheel H1, height 1.33
600.1240	Third wheel
550.1243	Fourth wheel
550.1246	Minute wheel
600.1250	Sweep second pinion, height 5.04
600.1250b	Sweep second pinion H1, height 5.19
610.1250	Sweep second pinion, height 5.54
600.1255	Friction spring for sweep second pinion

Escapement and balance (22)

550.1305	Escape wheel pivoted
550.1312	Pallet staff
470.1313	Exit pallet jewel
470.1314	Entry pallet jewel
550.1316	Jewelled pallet fork and staff
360.1317	Stud for hairspring
330.1318	Collet for hairspring
550.1321	Balance staff, pivoted
470.1322	Roller jewel
500.1324	Roller
550.1327	Balance with hairspring, regulated
601.1332	Regulator pointer
601.1333	Two-piece regulator
710.1339	Adjuster for regulator
330.1341	In-settings, upper and lower
100.1342	Cap jewels for balance, upper and lower
330.1344	End-piece holder, upper and lower
100.1345	Incabloc bolt
550.1346	Incabloc, lower
550.1347	Incabloc, upper
244.1350	Incabloc bolt
550.1363	Stud-holder

Screws (13)

2061	Screw for barrel bridge; also train wheel bridge, balance cock
2105	Screw for click
2109	Screw for crown wheel core
2154	Screw for stud for hairspring
2211	Screw for fixing enlargement ring
2247	Screw, 354 section
2255	Screw for casing clamp
2270	Screw for lower Incabloc
2503	Screw for plate clamp ring; also dial
2624	Screw for setting lever spring
2642	Screw for gib of rotor; also pressure spring for setting lever (601)
3437	Screw for pallet cock; also sweep second cock
3438	Screw for ratchet wheel

Jewels (7)

4059	Jewel for center wheel, lower
4102	Jewel for third wheel, lower; also fourth wheel, lower
4141	Jewel for escape wheel, upper
4169	Jewel for sweep second pinion, upper
4170	Jewel for third wheel, upper; also fourth wheel, upper
4171	Jewel for escape wheel, lower; also pallet staff, lower
4172	Jewel for pallet staff, upper

Other (2)

6153	Bushing for barrel arbor, upper
6154	Bushing for centre wheel, upper