Omega calibre 354 · parts by number

Automatic (bumper), centre seconds · diameter 28.10 mm · height 5.40 mm · 19,800 vph · 17 jewels · base calibre 330
Part numbers and names as printed in the Omega spare parts catalogue GF 620-1 (some heights from GF 620-3). 122 numbers. The prefix shows the calibre each part was first made for.

Plates and bridges (16)

351.1000	Plate
354.1001	Barrel bridge
350.1003	Train wheel bridge
330.1005	Pallet cock
344.1006	Balance cock
351.1007	Sweep second cock
351.1009	Bridge
330.1010	Lower bridge for oscillating weight
330.1012	Banking stop
351.1012	Bridge
330.1013	Upper bridge for oscillating weight
351.1013	Bridge
330.1017	Oscillating weight
351.1017	Bridge
330.1022	Plate-fastener
342.1023	Automatic component

Winding and setting (14)

330.1100	Ratchet wheel
330.1101	Crown wheel
330.1102	Crown wheel core
330.1104	Click
240.1105	Click spring
340.1106	Winding stem
330.1107	Clutch wheel
300.1108	Winding pinion
330.1108	Winding pinion
330.1109	Setting lever
330.1110	Setting lever spring
330.1111	Yoke
330.1112	Yoke spring
330.1113	Setting wheel

Check every number against your movement and supplier before ordering. Not affiliated with Omega.

Barrel, train and motion work (17)

330.1200	Barrel with arbor
330.1204	Barrel arbor
350.1208	Mainspring
330.1209	Brakespring
351.1218	Cannon pinion
354.1219	Cannon pinion H1, height 2.35
351.1224	Centre wheel with cannon pinion
354.1225	Centre wheel with cannon pinion, height 4.48
351.1231	Hour wheel
354.1232	Hour wheel H1, height 1.55
350.1240	Third wheel
350.1243	Fourth wheel
330.1246	Minute wheel
350.1249	Driving wheel over third wheel
351.1250	Sweep second pinion
354.1250b	Sweep second pinion, height 5.70
350.1255	Friction spring for sweep second pinion

Escapement and balance (24)

330.1305	Escape wheel pivoted
330.1312	Pallet staff
330.1313	Exit pallet jewel
330.1314	Entry pallet jewel
330.1316	Jewelled pallet fork and staff
330.1317	Stud for hairspring
330.1318	Collet for hairspring
330.1320	Hairspring, regulated
330.1321	Balance staff, pivoted
240.1322	Roller jewel (ellipse)
330.1324	Roller
330.1325	Balance
330.1326	Balance with roller, pivoted
330.1327	Balance with hairspring, regulated
332.1331	Regulator (regulator ring)
344.1332	Regulator pointer
344.1333	Two-piece regulator
330.1341	In-settings, upper and lower
100.1342	Cap jewels for balance, upper and lower
330.1344	End-piece holder, upper and lower
100.1345	Incabloc bolt
330.1346	Incabloc, lower
332.1347	Incabloc, upper
344.1356	Regulator group component

Automatic works (10)

330.1400	Oscillating weight axle
332.1403	Oscillating weight bearing, mounted
330.1405	Core for pawl-bearing yoke
330.1407	Pawl-bearing yoke with stud and spring
350.1410	Driving gear for crown wheel
330.1411	Impulse click spring
330.1412	Impulse click
330.1413	Stop click spring
330.1414	Stop click
332.1415	Banking stop springs

Screws (30)

2003	Screw for barrel bridge; also train wheel bridge, balance cock, upper bridge of oscillating weight
2016	Screw for upper and lower bridge of oscillating weight
2108	Screw for click
2109	Screw for crown wheel core
2110	Screw for pallet cock
2115	Screw for ratchet wheel
2138	Screw (its job depends on the calibre)
2142	Screw for banking stop
2145	Screw for case spring; also casing clamp
2154	Screw for stud for hairspring
2163	Screw for case spring for waterproof case
2165	Screw for casing (dog-screw) ring
2166	Screw for sweep second cock
2189	Screw for oscillating weight bearing
2247	Screw, 354 section
2248	Screw, 354 section
2249	Screw for oscillating weight segment (segment with 2 screws)
2407	Screw for setting lever
2501	Screw for dial
2503	Screw for plate clamp ring; also dial
2606	Screw for setting lever spring
2608	Screw for lower bridge of oscillating weight
2609	Screw for driving gear for crown wheel
2705	Screw for case (dog-screw)
2800	Screw for impulse click
2801	Screw for stop click
2805	Screw for stop click spring
2915	Screw for balance
2926	Screw for balance (heavy)
2927	Screw for balance (light)

Jewels (9)

4009	Jewel for oscillating weight, upper
4010	Jewel for oscillating weight, lower
4208	Jewel for escape wheel, lower
4209	Jewel for pallet fork, upper and lower
4212	Jewel for third wheel, upper; also fourth wheel, upper
4213	Jewel for third wheel, lower
4214	Jewel for fourth wheel, lower
4215	Jewel for escape wheel, upper
4217	Jewel for third wheel, upper

Other (2)

330.1910	Casing spring
6109	Bushings for driving gear of crown wheel, upper and lower