# Omega calibre 625 · parts by number

Manual wind · diameter 17.50 mm · height 2.50 mm · 21,600 vph · 17 jewels

Part numbers and names as printed in the Omega Technical Guide (TG 19). 66 numbers.

## Plates and bridges (4)

| | |
|---|---|
| **625.1000** | Main plate |
| **625.1002** | 3/4 plate bridge with movement number |
| **625.1005** | Pallet cock |
| **625.1030** | Balance cock |

## Winding and setting (16)

| | |
|---|---|
| **625.1100** | Ratchet wheel |
| **625.1101** | Crown wheel |
| **625.1102** | Crown wheel core |
| **625.1104** | Click |
| **625.1105** | Click spring |
| **620.1106** | Winding stem |
| **625.1107** | Clutch wheel |
| **625.1108** | Winding pinion |
| **625.1109** | Setting lever |
| **625.1110** | Setting lever spring |
| **625.1111** | Yoke |
| **625.1112** | Yoke spring |
| **625.1113** | Setting wheel |
| **620.1125** | Winding stem, long |
| **620.1159** | Two-piece winding stem, movement stem, short |
| **620.1160** | Two-piece winding stem, movement stem, long |

## Barrel, train and motion work (15)

| | |
|---|---|
| **625.1200** | Barrel with arbor |
| **625.1204** | Barrel arbor |
| **625.1208** | Mainspring |
| **625.1216** | Centre wheel |
| **625.1218** | Cannon pinion h0, height 1.90 mm |
| **625.1219** | Cannon pinion h1, height 2.15 mm |
| **625.1220** | Cannon pinion h2, height 2.40 mm |
| **625.1221** | Cannon pinion h3, height 2.65 mm |
| **625.1231** | Hour wheel h0, height 1.06 mm |
| **625.1232** | Hour wheel h1, height 1.31 mm |
| **625.1233** | Hour wheel h2, height 1.56 mm |
| **625.1234** | Hour wheel h3, height 1.81 mm |
| **625.1240** | Third wheel |
| **625.1243** | Fourth wheel |
| **625.1246** | Minute wheel |


Check every number against your movement and supplier before ordering. Not affiliated with Omega.

## Escapement and balance (14)

| | |
|---|---|
| **625.1305** | Escape wheel |
| **625.1316** | Pallet fork |
| **620.1324** | Roller |
| **625.1327** | Balance, complete |
| **625.1334** | Regulator |
| **1010.1341** | In-settings, upper and lower |
| **625.1341** | Incabloc in-setting, lower |
| **440.1342** | Cap jewel for balance |
| **1120.70901** | Cap jewel for balance, upper |
| **1010.1344** | End-piece holder for balance, upper and lower |
| **625.1344** | Cap jewel holder for balance, lower |
| **625.1346** | Incabloc, lower |
| **625.1347** | Incabloc, upper |
| **625.1363** | Stud holder |

## Screws (7)

| | |
|---|---|
| **2187** | Screw for pallet cock |
| **2216** | Screw for ratchet wheel |
| **2385** | Screw for 3/4 plate bridge; also balance cock and setting lever spring |
| **2559** | Screw for crown wheel core (right-hand); also screw for click |
| **2595** | Screw for stud |
| **2729** | Screw for crown wheel core (left-hand thread) |
| **1072621** | Screw for casing clamp |

## Jewels (9)

| | |
|---|---|
| **4046** | Jewel for center wheel, upper |
| **4047** | Jewel for center wheel, lower |
| **4208** | Jewel for escape wheel, lower |
| **4209** | Jewel for pallet fork, upper and lower |
| **4261** | Jewel for third wheel, upper; also fourth wheel, upper |
| **4262** | Jewel for third wheel, lower; also fourth wheel, lower |
| **4263** | Jewel for escape wheel, upper |
| **4274** | Jewel for third wheel, upper |
| **4296** | Jewel for third wheel, lower |

## Other (1)

| | |
|---|---|
| **6211** | Dial fastener |